

## **PORSCHE OBDII DTC**

|       |                                |
|-------|--------------------------------|
| P1036 | positive                       |
| P1102 | Oxygen Sensor Heating          |
| P1105 | Oxygen Sensor Heating          |
| P1107 | Oxygen Sensor Heating          |
| P1110 | Oxygen Sensor Heating          |
| P1115 | Oxygen Sensor Heating          |
| P1117 | Oxygen Sensor Heating          |
| P1119 | Oxygen Sensor Heating          |
| P1121 | Oxygen Sensor Heating          |
| P1123 | Oxygen Sensor Heating          |
| P1124 | Oxygen Sensing                 |
| P1125 | Oxygen Sensing                 |
| P1126 | Oxygen Sensing                 |
| P1127 | Oxygen Sensing                 |
| P1128 | Oxygen Sensing                 |
| P1129 | Oxygen Sensing                 |
| P1130 | Oxygen Sensing                 |
| P1136 | Oxygen Sensing                 |
| P1137 | Oxygen Sensing                 |
| P1138 | Oxygen Sensing                 |
| P1139 | Oxygen Sensing                 |
| P1140 | Load Signal                    |
| P1157 | Engine Compartment Temperature |
| P1158 | Engine Compartment Temperature |
| P1213 | Fuel Injector Cylinder 1       |
| P1214 | Fuel Injector Cylinder 2       |
| P1215 | Fuel Injector Cylinder 3       |
| P1216 | Fuel Injector Cylinder 4       |
| P1217 | Fuel Injector Cylinder 5       |
| P1218 | Fuel Injector Cylinder 6       |
| P1225 | Fuel Injector Cylinder 1       |
| P1226 | Fuel Injector Cylinder 2       |
| P1227 | Fuel Injector Cylinder 3       |
| P1228 | Fuel Injector Cylinder 4       |
| P1229 | Fuel Injector Cylinder 5       |
| P1230 | Fuel Injector Cylinder 6       |
| P1237 | Fuel Injector Cylinder 1       |
| P1238 | Fuel Injector Cylinder 2       |
| P1239 | Fuel Injector Cylinder 3       |
| P1240 | Fuel Injector Cylinder 4       |
| P1241 | Fuel Injector Cylinder 5       |
| P1242 | Fuel Injector Cylinder 6       |

P1265 Airbag Signal  
P1275 Oxygen Sensor Aging Ahead of Three Way Catalytic Converter  
P1276 Oxygen Sensor Aging Ahead of Three Way Catalytic Converter  
P1313 Misfire Cylinder 1 Emission Related  
P1314 Misfire Cylinder 2 Emission Related  
P1315 Misfire Cylinder 3 Emission Related  
P1316 Misfire Cylinder 4 Emission Related  
P1317 Misfire Cylinder 5 Emission Related  
P1318 Misfire Cylinder 6 Emission Related  
P1319 Misfire Emission Related  
P1324 Timing Chain out of Position Bank 2  
P1340 Timing Chain out of Position Bank 1  
P1384 Knock Sensor 1  
P1385 Knock Sensor 2  
P1386 Knock Control Test Pulse  
P1397 Camshaft Position Sensor 2  
P1411 Secondary Air Injection System  
P1455 A/C Compressor Control  
P1456 A/C Compressor Control  
P1457 A/C Compressor Control  
P1458 A/C Compressor Signal  
P1501 Fuel Pump Relay End-Stage  
P1502 Fuel Pump Relay End-Stage  
P1510 Idle Air Control Valve  
P1513 Idle Air Control Valve  
P1514 Idle Control Valve  
P1515 Intake Manifold Resonance Flap  
P1516 Intake Manifold Resonance Flap  
P1524 Camshaft Adjustment Bank 2  
P1530 Camshaft Adjustment Bank 1  
P1531 Camshaft Adjustment Bank 1  
P1539 Camshaft Adjustment Bank 2  
P1541 Fuel Pump Relay End-Stage  
P1551 Idle Air Control Valve  
P1552 Idle Air Control Valve  
P1553 Idle Air Control Valve  
P1555 Charge Pressure Characteristics  
P1556 Charge Deviations  
P1557 Charge Deviations  
P1570 Immobilizer  
P1571 Immobilizer  
P1585 Misfire With Empty Fuel Tank  
P1593 Intake Manifold Length Tuning 2  
P1594 Intake Manifold Length Tuning 2

P1595 Intake Manifold Length Tuning 2  
P1600 Voltage Supply  
P1601 Voltage Supply  
P1602 Voltage Supply  
P1610 MIL Activated Externally  
P1611 MIL Activated Externally  
P1614 MIL Activated Externally  
P1640 Engine Control Module  
P1656 Coolant Shutoff Valve  
P1671 Engine Compartment Purge Fan End-Stage  
P1673 Fan End-Stage  
P1689 Engine Control Module  
P1691 Malfunction Indicator Lamp  
P1692 Malfunction Indicator Lamp  
P1693 Malfunction Indicator Lamp  
P1704 Kickdown Switch  
P1710 Speed Signal Right Front  
P1715 Speed Signal Left Front  
P1744 Manual Program Switch  
P1746 Control Unit Detective (Relay)  
P1748 Control unit defective (Relay sticks)  
P1749 Version coding  
P1750 Voltage Supply Solenoid Valve Pressure Regulators 1  
P1761 Shiftlock P/N  
P1762 Shiftlock P/N  
P1764 Instrument cluster triggering  
P1765 Throttle-valve information error  
P1770 Load signal from ECM  
P1782 Engine Engagement  
P1813 Pressure regulator 1  
P1818 Pressure regulator 2  
P1823 Pressure regulator 3  
P1828 Pressure regulator 4